

FITTING INSTRUCTION

Clamp mark in acc. with		Cables joining
ISO	PN	
1	L	Left directional lights
2	+	Rear fog lights
3	31	Ground
4	R	Right directional lights
5	58R	Right side parking lights
6	54	Stoplights
7	58L	Left side parking lights





Fig. 2 Install – rear view

- Put distance sleeves (pos. 5) length $L=55\text{mm}$, from towbar accessories to chassis members, in drilled holes.
- Through prepared holes fix side brackets (pos. 4) using bolts $M12 \times 90\text{mm}$ (pos. 7) as shown on fig. 2.
- Between mounted side brackets put main bar of the towbar (pos. 1) and next through towbar holes fix it using bolts $M12 \times 35\text{mm}$ (pos. 8) from towbar accessories.
- To mounted bar fix tow-ball (pos. 2) using bolts $M16 \times 50\text{mm}$ (pos. 6).
- Fix socket plate (pos. 3) using bolt $M10 \times 30\text{mm}$ (pos. 9) as shown on the drawing.
- Tighten all bolts according to the torque shown in the table.
- Connect electric wires of 7-pole socket according to the instruction of the car. (Recommend to make at authorized service station)
- Complete paint layer damaged during installation.

This towbar is designed to assembly in following cars:

LUBLIN III 3,5t , loading platform, produced since 1999, catalogue no. **S14** and is prepared to tow trailers max total weight up to **2000 kg** and max vertical mass **75 kg**.

The instruction of the assembly

- Disassemble the rear step (if present), this element will be not used any more.
- Drill holes in chassis members using bit $\varnothing 22\text{mm}$. Left member from inside and right member from outside.

Torque settings for nuts and bolts (8,8):

M6 - 11 Nm	M 8 - 25 Nm	M 10 - 50 Nm
M 12 - 87 Nm	M 14 - 138 Nm	M16 - 210 Nm

NOTE

After install the towbar you should get adequate note in registration book (at authorised service station). The car should be equipped with:

- Indicators
- Tow mirrors

After **1000km** check all bolts and nuts. The ball of towbar must be always kept clear and conserve with a grease.

Towbar accessories:

Pos. 1 Main bar PCS.: 1	Pos. 5 Distance sleeve ø21,3x2,65mm L=55mm PCS.: 6	Pos. 11 Plain washer ø17mm PCS.: 2	Pos. 17 Nut 8 B M16 PCS.: 2
Pos. 2 Tow ball PCS.: 1	Pos. 6 Bolt 8,8 B M16x50mm PCS.: 2	Pos. 12 Plain washer ø13mm PCS.: 8	Pos. 18 Nut 8 B M12 PCS.: 14
Pos. 3 Socket plate PCS.: 1	Pos. 7 Bolt 8,8 B M12x90mm PCS.: 6	Pos. 13 Plain washer ø10,5mm PCS.: 1	Pos. 19 Nut 8 B M10 PCS.: 1
Pos. 4 Side bracket SZTUK: 2	Pos. 8 Bolt 8,8 B M12x35mm PCS.: 8	Pos. 14 Spring washer ø16,3mm PCS.: 2	Pos. 20 Ball cover PCS.: 1
	Pos. 9 Bolt 8,8 B M10x30mm PCS.: 1	Pos. 15 Spring washer ø12,2mm PCS.: 14	
	Pos. 10 Plain washer ø37xø13x3mm PCS.: 6	Pos. 16 Spring washer ø10,2mm PCS.: 1	



PPUH AUTO-HAK S.J.

Produkcja Haków Holowniczych
Henryk & Zbigniew Nejman
76-200 SŁUPSK ul. Słoneczna 16K
tel/fax (059) 8-414-414; 8-414-413
email: office@autohak.com.pl
www.autohak.com.pl

Towing hitch (without electrical set)

Class: **A50-X** Cat. no. **S14**

Designed for:

Manufacturer: **DAEWOO**

Model: **LUBLIN III 3,5t**

Type: **Loading platform**

produced since 1999

Technical data:

D-value: 11,9 kN

maximum trailer weight: **2000 kg**

maximum vertical cup load: **75 kg**

Approval number acc. to regulations EKG/ONZ 55.01: **E20 55R-01 1610**

Foreword

This towbar is designed according to rules of safety traffic regulations. The towing hitch is a safety component and must be installed only by qualified personnel. Any alteration or conversion to the towing hitch is prohibited and would lead to cancellation of design certification. Remove insulating compound and underseal from vehicle (if present) in the area of the matting surfaces of the towing hitch. The vehicle manufacturer's specifications regarding trailer load and max. vertical cup load are decisive for driving, and values for the towing hitch must not be exceeded.

D-value formula:

$$\frac{\text{Max trailer weight [kg]} \times \text{Max vehicle weight [kg]}}{\text{Max trailer weight [kg]} + \text{Max vehicle weight [kg]}} \times \frac{9,81}{1000} = D \text{ [kN]}$$